





Anti Vandal Toggle Switch Ø 22mm



| Switching Functions | POS.3 | POS.2 | POS.1 |
|-----------------------|-------|-------|-------|
| 2 - OFF - ON | OFF | - | ON |
| 3 - OFF - (ON) | OFF | - | (ON) |
| C - ON - OFF - ON | ON | OFF | ON |
| D - ON - OFF - (ON) | ON | OFF | (ON) |
| J - (ON) - OFF - (ON) | (ON) | OFF | (ON) |

NOTES: 1. Lever do not stop at "0" position.
2. () = Denotes function is momentary