

RJSAS30E SERIES

PUSH BUTTON SWITCH



Appearance

Model


Contact Type

Operation Type

Colour

Rated Voltage

Flush Push Button



-2110	1NO
-2101	1NC
-2120	2NO
-2102	2NC
-2111	1NO + 1NC
-3110	1NO
-3101	1NC
-3120	2NO
-3102	2NC
-3111	1NO + 1NC

Momentary

Maintained

K Black
G Green
R Red
B Blue
W White
Y Yellow

Illuminated Flush Push Button



-2710	1NO
-2701	1NC
-2720	2NO
-2702	2NC
-2711	1NO + 1NC
-3710	1NO
-3701	1NC
-3720	2NO
-3702	2NC
-3711	1NO + 1NC

Momentary

Maintained

G Green
R Red
B Blue
W White
Y Yellow

D 24VDC
E 12VDC
F 6.3VDC
A1 110VAC
A2 220VAC

Flat Round Push Button




-21S10	1NO
-21S01	1NC
-21S20	2NO
-21S02	2NC
-21S11	1NO + 1NC
-31S10	1NO
-31S01	1NC
-31S20	2NO
-31S02	2NC
-31S11	1NO + 1NC

Momentary

Maintained

Illuminated Flat Round Push Button



-27S10	1NO
-27S01	1NC
-27S20	2NO
-27S02	2NC
-27S11	1NO + 1NC
-37S10	1NO
-37S01	1NC
-37S20	2NO
-37S02	2NC
-37S11	1NO + 1NC

Momentary

Maintained

G Green
R Red
B Blue
W White
Y Yellow

D 24VDC
E 12VDC
F 6.3VDC
A1 110VAC
A2 220VAC

Dimensions

